



NUU ClickMate – English User Manual

INSTALLATION

1. Insert your iPhone 4/4S into the ClickMate Foundation Case.
 - a. Hold the case with the open side facing you and make sure that the volume and ringer cutout are on the left edge.
 - b. Insert your iPhone into the case, left edge first, ensuring that you line up the volume and ringer switches with the appropriate holes before firmly pressing the iPhone into the case.
2. With the iPhone screen facing you, slide the 30-pin connector of the ClickMate PowerPlus into the bottom of your iPhone.
3. Gently squeeze the PowerPlus and your iPhone together until you hear a click. The click indicates the locking mechanism has engaged and the devices are secured together.

NOTE: Your iPhone 4 or iPhone 4S must be in the ClickMate Foundation case in order for the locking mechanism to work.

4. You will hear the standard iPhone “chirp” or feel a vibration alert as it connects to the PowerPlus and begins drawing power.



POWER MODES

Normal Mode

The PowerPlus takes over as the primary power source when connected to your iPhone. Depending on its charge level, it will:

1. Charge your iPhone. The PowerPlus will charge your iPhone to full if need be.
2. Power your iPhone. After fully charging your iPhone, the PowerPlus will then power it, preserving the internal battery of your iPhone.

Standby Mode


Standby Mode allows you to save the PowerPlus’s charge for when you need it most. Turn on standby mode to use the internal battery of your iPhone.

Turn ON Standby Mode

1. Press and hold the On/Off button for three seconds.
2. The LED indicator lights will switch off and the iPhone charging icon will no longer display.
3. The ClickMate PowerPlus is now in standby mode.

Turn OFF Standby Mode

1. Press and hold the On/Off button for three seconds.
2. The iPhone will chirp/vibrate and the charging icon will display on the screen.
3. The ClickMate PowerPlus is now out of standby mode.



- 1 – On/Off Button
2 – LED Indicators

BATTERY STATUS INDICATOR LIGHTS

The PowerPlus has four LEDs on its bottom edge. These show the current battery level and charging status.

Battery Level

To check the battery level, press and release the On/Off button. The LEDs will light up momentarily and display according to the chart below.

LEDs Lit	Power Remaining
4	75% or more
3	50 – 75%
2	25 – 50%
1	10 – 25%
Blinking Light	Less than 10%
No lights	Needs to be charged

Note: The indicator lights do NOT show the status of the internal iPhone battery.

Charging Status

While connected to an external power source via the micro USB cable, the LEDs show the charging status.

LEDs Lit	LEDs Blinking	Charging Complete
0	1	0 - 25%
1	1	25 – 50%
2	1	50 – 75%
3	1	75 – 99%
4	0	100%

CHARGING THE ClickMate PowerPlus

You can charge both your iPhone and the PowerPlus without disconnecting either. Your iPhone will charge first, followed by the PowerPlus.



1. Insert the small end of the included micro USB cable into the PowerPlus.
2. Insert the other end of the micro USB cable into your computer or your iPhone USB wall adaptor.
3. Your iPhone will chirp/vibrate when the power connection is established and charging begins.

You may also sync and charge at the same time. When you connect the PowerPlus to a computer with the included micro USB cable, your iPhone will sync through it just as if you were using the standard Apple cable.

WARNING: Use only the supplied micro USB cable to ensure that your iPhone and PowerPlus are charged properly. Using the incorrect micro USB cable could result in damage to your iPhone and/or ClickMate PowerPlus as well as void the warranty.

REMOVAL

1. Hold the iPhone so the phone screen is in the palm of your hand and the back of the PowerPlus is facing up.
2. Locate the switch of the locking mechanism. Slide the spring-action switch upwards to unlock.
3. The PowerPlus will unhinge from the Foundation Case. **Do not pull the PowerPlus away while the 30-pin connector is still inserted in your iPhone!**
4. Slide the PowerPlus down to separate it from your iPhone.



RESETTING THE ClickMate PowerPlus

If you encounter any operational problems with the PowerPlus, the device can be reset as follows:

1. Connect the PowerPlus to a power source using the supplied micro USB cable and either your iPhone wall adaptor, or a computer.
2. The LED indicators will light up as the unit is being charged.
3. Press and hold the On/Off Button for about ten seconds until the LEDs turn off.

WARNINGS

- Read all instructions and warnings before using this product. Improper use of this product may result in, excess heat, toxic fumes, fire, explosion, or product damage for which you shall be responsible. Do not store battery in high temperature environments, including direct sunlight.
- Do not place battery in fire or expose to other sources of excessive heat. Do not expose battery to excessive impact or other physical abuse. Discontinue use of the product if there is any damage to the battery such as corrosion, dents, punctures, tears, or other deformities. If product is damaged in such a way, contact the manufacturer or dispose of it properly according to your local ordinances.
- Do not disassemble this product or attempt to modify it in any manner.
- Do not expose this product to moisture or submerge it in liquid. Keep the battery dry at all times.
- Do not wash the product with harsh chemicals, soaps or detergents. Wipe the casing with a soft, water-dampened cloth. Wipe the pins gently with a soft, dry cloth.
- Do not attempt to charge the battery using any method, apparatus or connection other than the device’s USB connector. For details and instructions on charging, refer to the “Charging the ClickMate PowerPlus” section of this manual.
- Do not attempt to replace any part of this product.
- All batteries have gone through a thorough quality assurance inspection. If you find that your battery is excessively hot, is emitting odor, is deformed, abraded, cracked or is demonstrating an abnormal phenomenon, stop all use immediately and contact the manufacturer.
- For extended storage, charge your battery for one hour before putting it away.
- Never dispose of batteries in the garbage, as this is considered unlawful under state and federal environmental laws and regulations. Always take used batteries to your local battery-recycling center.

DISCLAIMER

This battery is meant for use only in conjunction with the appropriate mobile device. Please consult the packaging to determine whether this product is compatible with your mobile device. Manufacturer is not responsible for any damages to any mobile device incurred through the use of this product.

Manufacturer shall not in any way be liable to you or to any third party for any damages you or any third party may suffer as a result of use, intended or unintended, or misuse of this product in conjunction with any device or accessory other than the appropriate mobile device for which this battery is designed. Manufacturer will not be responsible for any damages you or any third party may suffer as a result of misuse of this product as outlined above. If you are responsible for battery use with an unintended mobile device and damages result from such use, you agree to indemnify Manufacturer for any resulting injuries to any third party/parties. NUU is a registered trademark of NUU Limited. iPhone is a trademark of Apple Inc., registered in the U.S. and other countries. All rights reserved.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FAQ

Can I use the USB wall adaptor that came with my iPhone to charge the PowerPlus?

Yes, there is no problem with using your iPhone USB wall adaptor. In fact, charging with the wall adaptor lets you charge your PowerPlus faster and more efficiently.

Can I use any micro USB cable to charge the PowerPlus?

No, you should use only the cable that is supplied with the product. If you use a different cable, the charge times and behaviors stated in this manual may be different.

Can I charge my iPhone and PowerPlus at the same time?

Yes, you can charge your iPhone while the PowerPlus is still connected using the supplied micro USB cable. Your iPhone will charge first, followed by the PowerPlus. If you use your computer to charge the devices, your iPhone will also sync with iTunes.

How much extra battery life will the PowerPlus give my iPhone?

The PowerPlus has a capacity of 1600mAh, which is approximately 75% of the total capacity of a new iPhone 4 or iPhone 4S.

Does the PowerPlus interfere with antenna reception?

No, there should be no impact on antenna reception.

COMPATIBILITY

Made for iPhone 4S and iPhone 4

PACKAGE CONTENTS

1. NUU ClickMate PowerPlus with Foundation Case
2. Micro USB Cable
3. User Manual